

LOD OFFROAD

Jeep JK 2012 Relocation Bracket Installation Instructions

1. The 2012 Jeep Wrangler has a vacuum switch located within the frame rails. This vacuum switch will need to be relocated to allow room for the LoD winch plate.



2. Begin by removing the green clip that secures the vacuum line to the switch. Simply slide the clip down and pull the line off the switch.



3. Remove the two nuts that secure the switch. You can leave the switch wiring connected. Move the switch away from the mounting tab with studs.



4. With the switch out of the way cut the tab off that is closest to the front of the Jeep as shown in the photo.



5. Place the LoD relocation bracket up under the cross member as shown in the pic. Bolt the bracket on using the bolts provided with the kit. The bracket will mount directly up to existing holes so there is no drilling required.



6. With the bracket installed bolt the vacuum switch to the bracket as shown. The switch will be repositioned on its side in the new bracket.



7. Bolt the switch into place on the bracket.



8. Connect the vacuum lines that were removed earlier.



9. When finished the vacuum switch should look like the pic to the right.

