

LoD Offroad

Dodge 2500-3500 – Rear Bumper Installation Instructions

Please read through the instructions before beginning any part of the installation process.

1) Remove the factory bumper from the truck. Also remove the rear wiring harness located in the bumper.



2) Also remove these brackets from the rear of the frame. Keep the four small bolts from these mounts because you will need them to re-mount the new bumper.

Note: Before installing the new bumper it is easier to install the trailer plug, reverse sensors, wiring harness and lights into the bumper.



3) The new bumper is designed with adjustable mounts so be sure to spend some time properly aligning the bumper. (Note: It is important to carefully check the bumper clearance with the tailgate opened. The tailgate is designed as an arch which causes it to get much closer to the bumper in the open position. Not doing this may cause DAMAGE to the tailgate!) Once the bumper has been properly aligned you may tighten all the bolts so it doesn't move. Be sure to check your local laws as to whether you will need to install lighting for the license plate. We recommend using led license plate lights for this.